

# PolarCPC Activator



---

Read carefully all these instructions before continue with the activation procedure.

The activation procedure consists of two simple steps:

**STEP 1** (\* With original MMI 3G/3G+ unit installed on car)

1. Switch on car ignition
2. Switch on your MMI and wait until it starts
3. Now connect your activator to the car OBD2 port
4. In the activator a green light will start blinking, simply wait a minute until it stop blinking and keeps on
5. Disconnect your activator from the car, and switch of the ignition



**STEP 2** (\* Now remove your original MMI 3G/3G+ unit and install the new MMI 3G/3G+ in your car)

1. Switch on car ignition
2. Switch on your MMI and wait until it starts
3. Now, before connect the activator to the OBD Port, **keep pressed the activator push button**
4. **Without release the push button**, connect your box to the OBD Port
5. In the activator a green light will start blinking, simply wait a minute until it stop blinking and keeps on
6. Disconnect your activator from the car, and switch of the ignition
7. The navigation unit will take a minute to start again due the activator reset it after finish the process

**IMPORTANT** : It is not a problem if original unit is MMI 3G and the new unit is MMI 3G+

## Navigation units currently supported

---

PolarCPC activator will work ONLY is this navigation units, have in mind before start procedure :

- MMI 3G Low
- MMI 3G High
- MMI 3G+ Low
- MMI 3G+ High